USER'S MANUAL

USB 2.0

Multi Card Reader

Index Page

Introduction…… 1
Features…….. 1
Specification…….. 1
Requirements…… 2
Package contents…… 2

Chapter 1
Hardware Installation…… 3

Chapter 2
Software Installation…..…… 4

Introduction：

The USB2.0 Multi Card Reader/Writer supports the memory card as below:

- ☆ SD/Mini SD
  MMC/RS-MMC
- ☆ MS/ MS-PRO/ MS Magic Gate / MS Memory Select Function/MS-PRO Magic Gate/MS-PRO Ultra II/MS-ROM Card/ MS-PRO DUO/ MS-DUO/MS-PRO DUO Magic Gate/MS-DUO Magic Gate
- ☆ SM(SMC) /XD Card
- ☆ CFI / CFII/Micro Drive(MD).

Features：

USB	✧ Support USB 1.1/2.0 interface. ✧ USB and ACPI compliant. ✧ Support USB High –speed: 480M bps /Full-Speed 12Mbps. ✧ Truly Plug & Play automatic system configuration.
Power	✧ USB Bus power only.

Specification：

Interface	✧ Universal Serial Bus (USB) Revision 1.1/2.0 device.
Connectors list (optional)	☆ SD/Mini SD MMC/RS-MMC ☆ MS/ MS-PRO/MS Magic Gate / MS Memory Select Function/MS-PRO Magic Gate/MS-PRO Ultra II /MS-ROM Card/MS-PRO DUO/ MS-DUO/ MS-PRO DUO Magic Gate/MS-DUO Magic Gate ☆ SM(SMC) /XD Card ☆ CFI / CFII/Micro Drive(MD).
Cable	☆ USB cable (A type male to mini B type) ☆ USB extension cable A female to A male type (optional)
LED	✧ Active LED
	✧ Power LED

Requirements：

- ✧ IBM or other Compatible PCs / Mac G4
- ✧ USB 1.1/2.0 Host or USB 1.1/2.0 HUB device.
- ✧ Windows 98SE, Windows ME, Win2000 or Windows XP operating system or above.

Packing contents：

Item
USB 2.0 Multi Card Reader/Writer
Software CD Driver include User's Manual
Cable Type : USB Extension cable (A male to mini B type) USB extension cable A female to A male type (optional)

Chapter 1

INSTALLATION NOTICE:

***Please install driver before plugging Card Reader.

Hardware Installation ：

Business Card Size : (With mini B connector)

Active LED：Read/Write Indicate.
Power LED：Power LED Indicate.

Front view：

1. CFI/II/MD
2. SM(SMC) / XD card(optional)
3. MS /MS PRO
4. SD/MMC/ cards

Chapter 2

Software Installation：

.Windows98SE and Windows 2000

Step1：Please Insert the Installation CD into CD-ROM.

Step2：Please double click *“Driver”* folder

Step3：Please double Click ”Setup.exe” as below.



Step4: Please select your language for installation as below.



Step5：Please click “Next” to continue.


Multi-Card Reader & Flash Disk Setup
Welcome to the InstallShield Wizard for Multi-Card Reader & Flash Disk
The InstallShield?Wizard will install Multi-Card Reader & Flash Disk on your computer. To continue, click Next.
< Back
Next >
Cancel

Step6：Please click “Next” to continue.


Multi-Card Reader & Flash Disk Setup
Select Features
Select the features setup will install.
Select the features you want to install, and deselect the features you do not want to install.
Driver
Customized Icon
Description
Driver
2.09 MB of space required on the C drive
11410.04 MB of space available on the C drive
InstallShield
< Back
Next >
Cancel

Step7: The driver has been setup successfully. Please re-start the computer.


Multi-Card Reader & Flash Disk Setup
InstallShield Wizard Complete
Setup has finished installing Multi-Card Reader & Flash Disk on your computer.
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives, and then click Finish to complete setup.
< Back
Finish
Cancel

Step8 : When you plug Card reader and double click *"My Computer" after* PC being restarted. 4 kind of Icons will be appeared as Compact Flash (CF), Memory Stick (MS), Secure Digital (SD)/ MultiMedia Card and Smart Media.
(Icons for Win98SE and Win2000sp3 /sp4)

Step9: Please insert your memory cards and start to read and write .



Windows ME and Windows XP+Sp1

You do not need driver for installation if your Operation System is Windows ME or Windows XP, the system will detect driver automatically.
Turn On your computer, system will auto detect and down load the driver. You will see 4 removable disk icons in your File Manager. Now you can start to use the Card Reader/Writer. If you want to see 4 icons as below view for Multi Coloring icons, please follow step 1~ step7.



Mac 10.1.2 or above:

If your MAC O.S is 10.1.2 or above, you don't need driver for installation. Please plug-in the card reader and insert memory cards, now start to use the Flash Card Reader/Writer,
If your OS is 8.6 or 9.x, please copy the folder of Mac OS 8.6 or 9.X to your PC and follow instruction to install the driver.